

raspberrypi

información

- <https://www.raspberrypi.org/documentation/>
- <http://www.vichauter.org/como-se-hace/como-conectar-montar-discos-duros-usb-la-raspberrypi>

bash

- \$ sudo raspi-config
- \$ startx → arranca entorno gráfico
- \$ sudo reboot
- \$ cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_cur_freq
- \$ vim /etc/config.txt
 - arm_freq=700 # default 700, hasta 1500 (creo)
 - agp_freq=xxx #
- temperatura:
 - \$ cat /proc/acpi/thermal_zone/ATF0/temperature
 - \$ cat /sys/class/thermal/thermal_zone0/temp

reconfiguración teclado

- dpkg-reconfigure keyboard-configuration
- setupcon

IP estática

/vía: <https://pi-hole.net/faq/how-do-i-set-a-static-ip-address-in-raspbian-jessie-using-etcdhcpd-conf/>

- nano /etc/dhcpd.conf
- añadir:

```
interface eth0
static ip_address=192.168.1.141/24
static routers=192.168.1.1
static domain_name_servers=192.168.1.1
```

minecraft

- <http://picraftbukkit.webs.com/pi-minecraft-server-how-to>
 - no usar este server, usar el propio de minecraft, pero si instrucción de arranque
 - https://s3.amazonaws.com/Minecraft.Download/versions/1.8.4/minecraft_server.1.8.4.jar

WIFI (RASPI3)

- scan de redes wifi: sudo iwlist wlan0 scan

- configuración:
 - nano /etc/wpa_supplicant/wpa_supplicant.conf
 - añadir:

```
network={
    ssid="nombre_red"
    psk="wifi_password"
}
```

- debería automaticamente, al cabo de unos segundos, conectarse, pero:
 - reboot
 - sudo ifdown wlan0 y sudo ifup wlan0
- /vía: <https://www.raspberrypi.org/documentation/configuration/wireless/wireless-cli.md>

GPIO

Pibrella

- <http://simplesl.net/scratchgpio/addon-boards/pibrella/>
- <http://www.tecoed.co.uk/pibrella-alarm-system.html>
- http://www.amazon.es/gp/offer-listing/B00JACWLS5/ref=dp_olp_0?ie=UTF8&condition=all

From: <https://miguelangel.torresegea.es/wiki/> - **miguel angel torres egea**

Permanent link: <https://miguelangel.torresegea.es/wiki/raspi:start?rev=1462191086>

Last update: **02/05/2016 05:11**

